


Quick Start Guide


TP805L



Xiamen Hanin Electronic Technology Co.Ltd.
ADD: Room 305A, Angye Building,Pioneering Park,
Torch High-tech Zone,Xiamen,China 361009
Tel.: +86-(0)592-5885993
Fax: +86-(0)592-5885992
Web: www.hpert.com

Packing List

■ Standard Accessories



Printer



AC Adapter



Power Cord



USB Cable



Quick Start Guide



CD

■ Optional Accessories




Serial Cable

Note:


- 1) The packing materials are actually dependent on the order.
- 2) The AC adapter and power cord vary by local or region.

Appearance and Components


■ Front



■ Rear




■ Insight




Paper Loading


- 1.Press the cover open button to open the printer cover.
- 2.Remove the used roll paper core, if any.




- 3.In the correct direction of the roll paper, install the roll paper.



4.Pull out some roll paper, and close the printer cover.




5.Tear the extra paper in the direction of printer.





Power Supply

- 1.Make sure the printer is “OFF”.
- 2.Connect AC adapter with printer.
- 3.Connect AC adapter with power cord.
- 4.Plug the other side of power cord into the socket outlet.



Interface



Caution

When paper gets jammed, please turn the knob until the cutter blade returns to the normal position.

